
PIPIT

(RMP)



WARNING

- Ventilation of the room is necessary in order to keep the humidity low and to prevent mould in and around the bed
- Be aware of the risk of open fire and other sources of strong heat, such as electric bar fires, gas fires, etc. in the near vicinity of the bed
- Do not use the bed if any part is broken, torn or missing and use only spare parts approved by the manufacturer
- Do not leave anything in the bed or place the bed close to another product, which could provide a foothold or present a danger of suffocation or strangulation, e.g. strings, blind/curtain cords


- Always follow the manufacturer's instructions
- Do not use more than one mattress in the bed
- All assembly fittings should always be tightened properly and that fittings should be checked regularly and retightened as necessary
- Wooden and plastic parts should be cleaned using a dry cloth and ordinary, mild cleaning agents designed for cleaning raw wood


UWAGA

- Konieczna jest wentylacja pomieszczenia, aby utrzymywać niska, wilgotność i zapobiegać pleśni wokół łóżka
- Należy mieć świadomość ryzyka związanego z otwartym ogniem i innymi zagrożeniami źródeł silnego ciepła, takich jak grzejniki, kominki itp. w pobliżu łóżka
- Nie używaj tóżka, jeśli jakakolwiek część jest uszkodzona, złamana lub ich brakuje. Używaj wyłącznie zatwierdzonych części zamiennych przez producenta
- Nie zostawiaj niczego w tóżku ani nie kładź tóżka blisko innego produktu, który mógłby stwarzać ryzyko uduszenia lub zaplatania, np. sznurki, sznurki do rolet/firan

- Zawsze postępuj zgodnie z instrukcjami producenta
- Nie używaj więcej niż jednego materaca w tóżku
- Wszystkie śruby montażowe należy zawsze dokręcić prawidłowo, a także powinny być regularnie sprawdzane i w razie potrzeby dokręcane
- Części drewniane i plastikowe należy czyścić za pomocą suchej szmatki oraz zwykłych, łagodnych środków do pielegnacji i czyszczenia surowego drewna

MANUAL OF BED OVER 100 cm WIDE CAN BE FOUND ON PAGE 21







CZĘŚĆ/PART	NP	NL	DDP1	DDP2	DKP	DKB	B1	B2	SK	LDS	LKS	WS
ILOŚĆ/QUANTITY	2	2	1	2	4	1	2	1	4	2	1	1


ILOŚĆ/QUANTITY OF PL


DŁUGOŚĆ/LENGTH	SZEROKOŚĆ/WIDTH [cm]									
[cm]	70	80	90	100	120	135	140	160		
140	27	27	29	_	_	_	_	_		
160	28	28	30	_	_	_	_	_		
180	_	31	33	35	39	41	41	45		
190	_	33	35	37	41	43	43	47		
200	_	33	35	37	41	43	43	47		




CZEŚĆ/PART	S110	S80	S50	W30	K10	W16	G	KT
ILOŚĆ/QUANTITY	7	16	1	12	38	8	4	2











LEFT OR RIGHT SIDE

























MANUAL OF BED OVER 100cm WIDE







ST	
DŁUGOŚĆ/LENGTH [cm]	ILOŚĆ/QUANTITY
180	28
190	32
200	32

Р	
DŁUGOŚĆ/LENGTH [cm]	ILOŚĆ/QUANTITY
180	56
190	64
200	64

CZĘŚĆ/PART	WZ	DKWZ	NWZ	LKS	LDS	S50	K10	W45	W16	KT
ILOŚĆ/QUANTITY	1	2	3	1	2	2	4	3	8	2





TO PROPERLY SCREW DOWN THE BED LEG, SEE THE FIRST PART OF THE MANUAL, PAGE 15

